

OPERATING MANUAL

HD2013

Tipping bucket rain gauge



EN
V1.8



Contents

1	Introduction	3
2	Technical specifications.....	4
3	Installation.....	7
	3.1 Electrical connection.....	7
	3.2 Configuration of analog output.....	10
	3.3 Tipping bucket.....	11
	3.4 Installation modes	12
4	Serial commands	14
5	SDI-12 protocol.....	20
6	Maintenance	28
7	Safety instructions	29
8	Accessories ordering codes	30

1 Introduction

The HD2013 is a reliable and sturdy tipping bucket rain gauge, built entirely from corrosion resistant materials in order to guarantee its durability. So as to ensure accurate measurement even with low temperature climatic conditions or during and after precipitations of snow, a version with heating which is automatically activated around +4 °C has been developed so that snow deposits and ice formations are prevented.

The rain gauge is formed by a metal base on which a tipping bucket is set. The rain collector cone, fixed to the aluminum cylinder, channels the water inside the tipping bucket: once the predefined level is reached, the calibrated bucket rotates under the action of its own weight, discharging the water. During the rotation phase, the normally closed reed contact opens for a fraction of a second, sending an impulse to the counter.

The quantity of rainfall measured is based on the count of the number of times the bucket is emptied: the reed contacts, normally closed, open at the moment of the rotation between one bucket's section and the other. The number of impulses can be detected and recorded by a data logger or by a pulse counter.

The rain gauge is available with **4...20 mA** (HD2013...**A**...) or **0...10 Vdc** (HD2013...**V**...) **optional analog output** or with **optional SDI-12 digital output** (HD2013...**S**...).

The versions with analog or SDI-12 output are equipped with a backup battery that allows maintaining the rainfall information even after short power supply outages (at least 10 seconds for the versions with analog output, approx. 5 minutes for the version with SDI-12 output).

A removable filter for periodic cleaning and maintenance is inserted in the water collector cone so as to prevent leaves or other elements blocking the end of the hole. For a better water flow, the collecting cone is treated with a non-adherent product.

In the version with heating HD2013...**R**..., the heating circuit operates with 12 Vdc or 24 Vdc direct voltage (**to be specified when ordering**). Heating is activated around +4 °C.

The different models differ in the tipping bucket resolution, in the presence or absence of the optional analog or digital output and in the heating power supply:

HD2013

<p>Heating Blank = not heating R = heated – power voltage 24 Vdc R1 = heated – power voltage 12 Vdc</p>
<p>Output: Blank = contact A = contact + analog 4...20 mA V = contact + analog 0...10 V S = contact + digital SDI-12</p>
<p>Resolution Blank = 0.2 mm /1 = 0.1 mm /5 = 0.5 mm</p>

2 Technical specifications

Power supply	
Basic version	---
Heating	12 Vdc (HD2013 R1) or 24 Vdc (HD2013 R) \pm 10%
Analog output	7...30 Vdc (HD2013... A ...) / 13...30 Vdc (HD2013... V ...)
SDI-12 output	7...30 Vdc (HD2013... S ...)
Consumption	
Basic version	---
Heating	165 W (HD2013 R ...)
Analog output	26 mA max. @ 18 Vdc (HD2013... A ...)/ \approx 4 mA @ 18 Vdc (HD2013... V ...)
SDI-12 output	\approx 100 μ A @ 18 Vdc
Contact output	NC contact (opens during tipping). With analog or SDI-12 output options, the contact output is alternative to the analog or SDI-12 output and the rain gauge is factory-configured with analog or SDI-12 output.
Analog output	4...20 mA (HD2013... A ...) or 0...10 V (HD2013... V ...)
Digital output	SDI-12 (HD2013... S ...)
Resolution	0.1 – 0.2 or 0.5 mm/ tip depending on model
Accuracy	Version with 0.2 mm @ 50 mm/h nominal resolution: < 1% up to 30 mm/h < 2% up to 40 mm/h < 3% up to 60 mm/h < 4% up to 100 mm/h Version with 0.5 mm @ 50 mm/h nominal resolution: + 2...-3,5% in the interval 0...200 mm/h The error refers to the calculation of the amount of rain using the resolution stated in the rain gauge label. If the amount of rain is calculated using the correction curves as a function of the rainfall rate (see the graphs on the following pages), the error is typically less than \pm 2% in the interval 0...200 mm/h. If the HD2013-DB data logger is used, the measurement can be automatically compensated according to the correction curves. With the analog and SDI-12 output options, the curve is stored in the rain gauge itself.
Maximum rainfall rate	600 mm/h (versions with 0.1 and 0.2 mm nominal resolution) 1000 mm/h (version with 0.5 mm nominal resolution)
Operating temperature	
Without heating	0...+70 °C
With heating	-20...+70 °C (heating intervention temperature +4 °C)
Protection degree	IP 65
Collector area	400 cm ²
Dimensions	\varnothing 248 x 350 mm (excluding ground support feet or support for mast)
Minimum section of the connecting cable wires	0.5 mm ² without heating 2.5 mm ² for heating




Fig. 2.1 – Normalized resolution (0.1 mm @ 50 mm/h) as a function of the rainfall rate




Fig. 2.2 – Normalized resolution (0.2 mm @ 50 mm/h) as a function of the rainfall rate




Fig. 2.3 – Normalized resolution (0.5 mm @ 50 mm/h) as a function of the rainfall rate

To correct the measurement depending on the rainfall rate, it is necessary to log, in addition to the number of pulses, also the instants at which the pulses occur.

Example of measurement correction:

Let’s assume that a rain gauge with nominal resolution $R_N = 0.204 \text{ mm @ } 50 \text{ mm/h}$ has generated 25 pulses at the frequency of 1 pulse every 25 seconds.

The rainfall rate can be estimated considering the nominal resolution R_N and the interval between two successive pulses: $I \approx 0.204 \times 3600 / 25 \approx 29.38 \text{ mm/h}$.

From fig. 2.2 we obtain the normalized corrected resolution: $R_{Cn} = 0.198 \text{ mm}$.

The corrected resolution of the rain gauge is: $R_C = R_{Cn} \times R_N / 0.2 = 0.202 \text{ mm}$.

The amount of rain detected is $25 \times 0.202 = 5.05 \text{ mm}$.

3 Installation

The rain gauge is supplied already calibrated and the calibration value (resolution) is shown on the instrument label.

The instrument must be installed in an open area, away from buildings, trees, etc., ensuring the space over it is free from all objects which could obstruct rain measurements, and in an easily accessible position for the filter to be cleaned periodically.

Avoid installation in areas exposed to gusts of wind, turbulence (for example the top of a hill) as these may distort the measurements.

As standard, the rain gauge is supplied for ground installation, with three height-adjustable support feet for proper levelling of the instrument, and holes for possible later fixing to the floor (fig. 3.7).

The rain gauge can be installed raised above the ground using the optional **ACCR001** support (a mast with M37 internal thread on one side is required). To install the ACCR001 support, it is necessary to unscrew the 3 brackets with feet from the base of the rain gauge, then attach the support for mast as shown in fig. 3.8.

For the tipping device to function correctly and so for the measurement to be correct, it is important that the instrument is placed perfectly levelled. The base of the rain gauge is fitted with a bubble level.

For installation, unscrew the three screws at the base of the cylinder that supports the water collector cone.

Attention: a heating resistor is fitted around the cone in the heated version. To disconnect the cone heater, unplug the connector on the upper side of the terminal block protection cover (see fig. 3.1).

Eight bird spikes can be attached to the rain gauge (optional accessory **ACCR002**), which are screwed into the holes on the top ring of the rain gauge. **Be careful not to get hurt by sharp spikes.**

3.1 Electrical connection

For the version without heating use a 2-wire cable with 0.5 mm² minimum wires section, for the version with heating use a 4-wire cable with 2.5 mm² minimum wires section.

Use a shielded cable over long distances. Slide the cable through the cable gland and fasten it with the cable fastener located near the entry hole at the base of the rain gauge.

Unscrew the terminal block protection cover and perform the connections as shown in the following figures.

Connection of heating:

The heated version requires power (12 Vdc or 24 Vdc depending on the version supplied) for the resistors: perform the connection as indicated at point 2 of fig. 3.1.

If the connections are set correctly, the LED placed near the terminals will be lit up.

Connection of contact output:

The rain gauge contact output, indicated at point 1 in fig. 3.1, must be connected to a data logger or to a pulse counter.

To use the contact output in the versions with analog or SDI-12 output option, set the SW1 switch down, towards the EXTERNAL indication (see fig. 3.2 and 3.3): the analog

or SDI-12 output is disabled.




Fig. 3.1 - connections of contact output and heating

Connection of analog output (only HD2013...A... and HD2013...V...):

Perform the connections as shown in the following figure. Set the SW1 switch up, towards the INTERNAL indication (the contact output is disabled).




Fig. 3.2 – Connections of analog output

The current analog output is active. The maximum value of the load resistance depends on the power supply value:

$$R_L \text{ max} = 50 \times (V_{dc} - 7) \Omega$$

The minimum value of the load resistance for the version with voltage analog output is 10 K Ω .

In case of a measurement error, the analog output goes to the value 22 mA or 11 V.

The reset line allows the partial amount of rainfall measurement (amount of rainfall from the last reset command) to be remotely reset. During the measurement, the reset line must be connected to GND. To reset, disconnect the line from GND and apply a direct voltage of at least 3 Vdc (and lower than or equal to the power supply) for at least 1 s, then reconnect the line to GND.

Connection of SDI-12 digital output (only HD2013...S...):

Perform the connections as shown in the following figure. Set the SW1 switch up, towards the INTERNAL indication (the contact output is disabled).





Fig. 3.3 – Connections of SDI-12 digital output

The reset line is not used in the version with digital output: the reset is performed with the appropriate SDI-12 extended command (**aXDRES!**, with **a**=address of the rain gauge).

Connection of the optional CPM12AA4.x cable to the rain gauges with analog or SDI-12 output option:

Connector pin	Function	Wire color
1	Power supply positive (+Vdc)	Red
2	GND	Blue
3	Analog or SDI-12 output positive (OUT)	White
4	Cable shield	Black



The cable shield (black wire) can be left disconnected inside the rain gauge (isolate or cut the wire terminal to avoid unwanted contacts).

3.2 Configuration of analog output

The analog output is proportional to the partial amount of rainfall (amount of rainfall from the last reset command). The analog output full scale (20 mA or 10 V) can be associated with different values of rainfall. The association can be implemented via hardware, by using the **dip switches** on the circuit board, or via software, by connecting the serial communication port **COM PC** of the rain gauge to the PC.

The dip switches allow setting three rainfall values: 25, 100 or 250 mm (1, 5 or 10 inches if the set unit of measurement is "inches"), as shown in fig. 3.4.

If both the dip switches are set to ON, the rainfall value considered is the one set via serial port with the command **CRW** (see the table of the serial commands).




Fig. 3.4 – Dip switches

Warning: after reaching the full scale value, the measurement is reset and the analog output returns to the initial scale value.

3.3 Tipping bucket

The tipping bucket is locked for the transport of the rain gauge. To unlock the bucket, remove the holders as shown in the following figure.




Fig. 3.5 – Locking and unlocking the tipping bucket

The oscillation of the tipping bucket can be adjusted through the two threaded rods located under the bucket, as illustrated in the following figure.




Fig. 3.6 – Adjustment of the tipping bucket

3.4 Installation modes




Fig. 3.7 – Ground installation




Fig. 3.8 – Installation raised above ground

4 Serial commands

The rain gauges with analog or SDI-12 output option allow editing or checking the operating parameters of the instrument via serial commands.

The editing of the rain gauge parameters requires sending a password via the serial command **PWD**. By default, the password is not set; therefore, it is sufficient to send the command PWD without password to change the parameters. To protect the parameters from unauthorized changes, it is advisable to set a password with the serial command **SUP**. The password remains active for 10 minutes, after which you must resubmit it.

In the serial commands tables below, the column "PWD" indicates whether the execution of the command is password protected.

Rain gauge with analog output:

The configuration is done by connecting the rain gauge **COM PC** serial port to a PC (**RS27** cable for the RS232 connection, **CP27** cable for the USB connection) and sending, through a standard serial communication program, the commands given in the tables below (communication parameters 9600, 8N2).

Note: if the CP27 cable is used, install the corresponding USB drivers in your PC.

Rain gauge with SDI-12 output:

The configuration is done by connecting the rain gauge SDI-12 output and sending extended SDI-12 commands (communication parameters 1200, 7E1) in the following format:

<Address>XD<Command>!

With <Address> = address of the instrument the command is sent to
<Command> = one of the commands given in the tables below

For example, to set °F as temperature unit of measurement in the instrument with address 0, send:

0XDPWDmypass! *Sends the password (assuming password=mypass)*
0XDTUWF! *Sets °F*

The reply to an extended command is always preceded by the address of the instrument that replies.

Serial commands

In the editing commands, the new value of the parameter follows immediately (without spaces interposed) the command identifier.

Password management

Command	Description	PWD
PWDx...x	Sends the password x...x (8 characters max.). Reply of the instrument: USER ACCESS OK if the password is accepted WRONG PASSWORD if the password is not accepted	---
SUPx...x	Sets the string x...x (8 ASCII characters max.) as password. Reply of the instrument: PASS: x...x if the password is accepted INVALID PASSWORD if the password is not accepted	Yes

Date and time

Command	Description	PWD
DSyyyy/mm/dd hh:mm:ss	Sets the date yyyy/mm/dd (year/month/day) and the time hh:mm:ss (hour/minutes/seconds) in the rain gauge. Reply of the instrument: & if date and time are accepted ? if date and time are not correct	Yes
DG	Reads the date (year/month/day) and the time (hour/minutes/seconds) set in the rain gauge. Reply of the instrument: yyyy/mm/dd hh:mm:ss	No

General info

Command	Description	PWD
IR	Reads the manufacturer, the model, the firmware version and the serial number of the rain gauge. Reply of the instrument: v...vm...mf...fs...s, with: v...v (8 characters) = name of the manufacturer m...m (6 characters) = model f...f (3 characters) = firmware version s...s (max. 13 characters) = serial number	No

Unit of measurement

Command	Description	PWD
UWn	Sets the unit of measurement of index <i>n</i> for the amount of rainfall: <i>n</i> =0 ⇒ mm, <i>n</i> =1 ⇒ inches Reply of the instrument: & if the unit of measurement is accepted ? if the index <i>n</i> is not correct	Yes
UR	Reads the unit of measurement of the amount of rainfall set in the rain gauge. Reply of the instrument: 0 if the unit of measurement is "mm" 1 if the unit of measurement is "inches"	No
TUWu	Sets the temperature unit of measurement (*): <i>u</i> =C ⇒ °C, <i>u</i> =F ⇒ °F Reply of the instrument: & if the unit of measurement is accepted ? if the character <i>u</i> is not correct	Yes
TUR	Reads the temperature unit of measurement (*). Reply of the instrument: C if the unit of measurement is "°C" F if the unit of measurement is "°F"	No

(*) The rain gauges with analog or SDI-12 output option are equipped with a temperature sensor which detects the internal temperature of the instrument (**not the air temperature**). The temperature value can be read via the serial commands S1 / S2 or, in the rain gauges with SDI-12 output option, via the appropriate SDI-12 command described in the paragraph "SDI-12 protocol".

Resolution

Command	Description	PWD
BW <i>n</i>	<p>Sets the rain gauge resolution (amount of rainfall corresponding to an emptying of the tipping bucket) of index <i>n</i>:</p> <p><i>n</i>=0 ⇒ 0.1 mm <i>n</i>=1 ⇒ 0.2 mm <i>n</i>=2 ⇒ 0.25 mm <i>n</i>=3 ⇒ 0.5 mm <i>n</i>=4 ⇒ 1.0 mm <i>n</i>=5 ⇒ 0.254 mm (0.01 inches) <i>n</i>=6 ⇒ 0.508 mm (0.02 inches) <i>n</i>=7 ⇒ 1.016 mm (0.04 inches) <i>n</i>=X ⇒ custom value (set via the CCW command)</p> <p>Reply of the instrument: & if the resolution is accepted ? if the index <i>n</i> is not correct</p>	Yes
BR	<p>Reads the rain gauge resolution.</p> <p>The reply of the instrument is the index <i>n</i> of the resolution according to the list given in the description of the editing command BW.</p>	No
CCW <i>n...n</i>	<p>Sets <i>n...n</i> as custom value of the resolution. The value must be between 0.001 and 10.00 and is considered in the unit of measurement (mm or inches) set in the instrument.</p> <p>Example: CCW+0.42 sets 0.42 mm or 0.42 inches, depending on the unit of measurement set, as custom value of the resolution.</p> <p>Reply of the instrument: & if the value <i>n...n</i> is accepted ? if the value <i>n...n</i> is not correct</p> <p><i>Warning</i>: the command CCW sets the value but not the use of the custom resolution; to use the custom resolution, the command BWX should be sent (see the command BW described above).</p>	Yes
CCR	<p>Reads the custom value of the resolution. The value is considered in the unit of measurement (mm or inches) set in the instrument.</p>	No

Output contact type

Command	Description	PWD
TNW <i>n</i>	<p>Sets the rain gauge output contact as normally open or normally closed: <i>n</i>=0 ⇒ Normally OPEN, <i>n</i>=1 ⇒ Normally CLOSED</p> <p>Reply of the instrument: & if the setting is accepted ? if the index <i>n</i> is not correct</p>	Yes
TNR	<p>Reads the type of the rain gauge output contact.</p> <p>Reply of the instrument: 0 if the contact is normally OPEN 1 if the contact is normally CLOSED</p>	No

Analog output (only HD2013...A... and HD2013...V...)

Command	Description	PWD
CPOE	Enables the offset of the analog output initial value: 4...20 mA or 2...10 V. Reply of the instrument: &	Yes
CPOD	Disables the offset of the analog output initial value: 0...20 mA or 0...10 V. Reply of the instrument: &	Yes
CPOR	Reads the enabling state of the offset of the analog output initial value. Reply of the instrument: 0 if the offset is disabled (0...20 mA or 0...10 V) 1 if the offset is enabled (4...20 mA or 2...10 V)	No
CRW <i>n...n</i>	Sets <i>n...n</i> as the amount of rainfall corresponding to the analog output full scale. The value must be between 0.01 and 9999.00 and is considered in the unit of measurement (mm or inches) set in the instrument. Example: CRW+80.00 sets 80 mm or 80 inches, depending on the unit of measurement set, as value corresponding to 20 mA or 10 V. Reply of the instrument: & if the value <i>n...n</i> is accepted ? if the value <i>n...n</i> is not correct	Yes
CRR	Reads the amount of rainfall corresponding to the analog output full scale. The value is considered in the unit of measurement (mm or inches) set in the instrument.	No

Printing of the measurements

Command	Description	PWD
S0	Stops the continuous printing of the measurements. Reply of the instrument: &	No
S1	Single printing of the measurement values, considered in the unit of measurement set in the instrument. Reply of the instrument: $M_1 M_2 M_3 M_4 M_5$, with: M_1 = total amount of rainfall (from when the instrument is powered) M_2 = partial amount of rainfall (from the last reset operation) M_3 = amount of rainfall in the current day M_4 = amount of rainfall in the previous day M_5 = internal temperature Example: the reply +873.4+15.8+2.6+3.4+15.3 indicates that the internal temperature is 15.3 °C and the amount of rainfall is: 873,4 mm or inches from when the instrument is powered 15,8 mm or inches from the last reset operation 2,6 mm or inches today 3,4 mm or inches yesterday <i>Note:</i> after reaching 99999.99, the total rainfall counter restarts from zero.	No
S2	Continuous printing (once per second) of the measurement values, considered in the unit if measurement set in the instrument. The reply of the instrument is in the same form described for the command S1.	No

Reset

Command	Description	PWD
RES	Resets the partial rainfall counter. Reply of the instrument: &	Yes
REA	Resets all the rainfall counters. Reply of the instrument: &	Yes
HRS	Resets the electronic board (with consequent reset of all the measuring counters).	Yes

Correction of the measurement

To increase the measurement accuracy, a measurement correction table as a function of the rainfall rate is stored in the rain gauge at the factory.

The correction is useful because during the emptying time of the tipping bucket, rain is not collected from the bucket and the amount of rain in the absence of correction is therefore underestimated. The correction to be made is greater the higher is the rainfall rate (greater number of cycles in the time unit).

The correction table can be modified by the user. The rain gauge allows you to set ten multiplication factors (numbered from 0 to 9) of the nominal resolution, each corresponding to a range of rainfall rate.

Command	Description	PWD
TE	Enables the measurement correction as a function of the rainfall rate. Reply of the instrument: &	Yes
TD	Disables the measurement correction as a function of the rainfall rate. Reply of the instrument: &	Yes
TR	Reads the enabling state of the measurement correction as a function of the rainfall rate. Reply of the instrument: 0 if the correction is disabled 1 if the correction is enabled	No
CTS	Starts the correction table writing procedure. Reply of the instrument: CALIBRATION_STARTED	Yes
CTE	Ends the correction table writing procedure and saves the entered values. Reply of the instrument: CALIBRATION_ENDED	Yes
CTWi+r...r+k...k	Set the multiplication factor of index i to the value $k...k$. The multiplication factor is applied if the rainfall rate is between $r...r$ (considered in mm/h or in/h depending on the unit of measurement set in the instrument) and the rate value defined for the multiplication factor of index $i+1$ (see the example below). The multiplication factor must be between 0.500 and 2.000. The rainfall rate must be between 0 and 7200. Reply of the instrument: & if the parameters are correct ? if the parameters are not correct	Yes

Command	Description	PWD
CTR <i>i</i>	<p>Reads the setting of the multiplication factor of index <i>i</i>.</p> <p>Reply of the instrument: <i>r...rk...k</i>, with: <i>r...r</i> = rainfall rate corresponding to the multiplication factor <i>k...k</i> = value of the multiplication factor</p> <p>Example: +50+1 indicates that the multiplication factor is 1 and the corresponding rainfall rate is 50 (mm/h or in/h).</p>	No

When you set the correction table, it is mandatory to enter in ascending order all the ten multiplication factors. The rate corresponding to the multiplication factor of index *i* must be greater or equal to the rate corresponding to the multiplication factor of index *i*-1.

Example

To change the default table and implement the following correction table:

		Rainfall rate (mm/h)									
		0...25	25...75	75...100	100...150	150...200	200...250	250...300	300...350	350...400	400...
K		0.98	1	1.02	1.04	1.06	1.09	1.10	1.14	1.18	1.22

send, exactly in the order shown, the following commands:

```

CTS
CTW0+0+0.98
CTW1+25+1
CTW2+75+1.02
CTW3+100+1.04
CTW4+150+1.06
CTW5+200+1.09
CTW6+250+1.10
CTW7+300+1.14
CTW8+350+1.18
CTW9+400+1.22
CTE

```

Note that the sequence of the CTW commands must be preceded by the command CTS and followed by the command CTE.

5 SDI-12 protocol

The **HD2013...S...** rain gauge is equipped with an SDI-12 communication interface compliant with the version 1.3 of the protocol, which allows the connection to SDI-12 sensor networks.

The communication parameters of the protocol are:

- Baud Rate = 1200
- Data bits = 7
- Parity = Even (E)
- Stop bits = 1

Communication with the instrument is performed by sending a command in the following format:

<Address><Command>!

With <Address> = address of the instrument the command is sent to
<Command> = type of operation requested to the instrument

The instrument reply is as follows:

<Address><Data><CR><LF>

With <Address> = address of the replying instrument
<Data> = information sent by the instrument
<CR> = ASCII character *Carriage Return*
<LF> = ASCII character *Line Feed*

The table below shows the available SDI-12 commands. For consistency with the documentation of the SDI-12 standard, the instrument address is indicated in the table with the letter **a**. The rain gauge leaves the factory with address preset to 0. The address can be changed by using the proper SDI-12 command reported in the table.

SDI-12 Commands

Command	Instrument reply	Description
a!	a<CR><LF>	Verifies the presence of the instrument.
aI!	allccccccmmmmmmvvvsssssss<CR><LF> with: a = address of the instrument (1 character) ll = SDI-12 compliant version (2 characters) ccccccc = manufacturer (8 characters) mmmmmm = instrument model (6 characters) vvv = firmware version (3 characters) sssssss = serial number (8 characters)	Requests for information from the instrument.
aAb! Where: b =new address	b<CR><LF> Note: if the b character is not an acceptable address, the instrument responds with a instead of b.	Modification of the instrument address.
?!	a<CR><LF>	Request of the address of the instrument. If more than one sensor is connected to the bus, a conflict occurs.

Type M (start measurement) commands

Command	Instrument reply	Description
Total amount of rainfall		
aM!	atttn<CR><LF> with: ttt = number of seconds necessary for the instrument to make the measure available (3 characters) n = number of detected variables (1 character) Note: ttt = 000 means that datum is immediately available.	Request of detection of the total amount of rainfall.
aD0!	a+n+r...r<CR><LF> with: n = number of emptying of the tipping bucket r...r = total amount of rainfall in the unit of measurement set in the instrument (mm or inches) ⇒ Example of response: 0+48+9.6 The instrument with address 0 has recorded 48 emptying of the tipping bucket and the total amount of rainfall is 9.6 mm or inches depending on the set unit. <i>Note:</i> after reaching 99999.99, the total rainfall counter restarts from zero.	Reads the total amount of rainfall.
Partial amount of rainfall		
aM1!	atttn<CR><LF> with: ttt = number of seconds necessary for the instrument to make the measure available (3 characters) n = number of detected variables (1 character) Note: ttt = 000 means that datum is immediately available.	Request of detection of the partial amount of rainfall.
aD0!	a+n+r...r<CR><LF> with: n = number of emptying of the tipping bucket r...r = partial amount of rainfall in the unit of measurement set in the instrument (mm or inches) ⇒ Example of response: 0+12+2.4 The instrument with address 0 has recorded 12 emptying of the tipping bucket and the partial amount of rainfall is 2.4 mm or inches depending on the set unit. <i>Note:</i> after reaching 99999.99, the partial rainfall counter restarts from zero.	Reads the partial amount of rainfall.

Command	Instrument reply	Description
Amount of rainfall in the current day		
aM2!	atttn<CR><LF> with: ttt = number of seconds necessary for the instrument to make the measure available (3 characters) n = number of detected variables (1 character) Note: ttt = 000 means that data are immediately available.	Request of detection of the amount of rainfall in the current day.
aD0!	a+n+r...r<CR><LF> with: n = number of emptying of the tipping bucket r...r = amount of rainfall in the current day in the unit of measurement set in the instrument (mm or inches) ⇒ Example of response: 0+2+0.4 The instrument with address 0 has recorded 2 emptying of the tipping bucket and the amount of rainfall today is 0.4 mm or inches depending on the set unit.	Reads the amount of rainfall in the current day.
Amount of rainfall in the previous day		
aM3!	atttn<CR><LF> with: ttt = number of seconds necessary for the instrument to make the measure available (3 characters) n = number of detected variables (1 character) Note: ttt = 000 means that data are immediately available.	Request of detection of the amount of rainfall in the previous day.
aD0!	a+n+r...r<CR><LF> with: n = number of emptying of the tipping bucket r...r = amount of rainfall in the previous day in the unit of measurement set in the instrument (mm or inches) ⇒ Example of response: 0+8+1.6 The instrument with address 0 has recorded 2 emptying of the tipping bucket and the amount of rainfall yesterday was 1.6 mm or inches depending on the set unit.	Reads the amount of rainfall in the previous day.

Command	Instrument reply	Description
Rainfall rate		
aM4!	attn<CR><LF> with: ttt = number of seconds necessary for the instrument to make the measure available (3 characters) n = number of detected variables (1 character) Note: ttt = 000 means that data are immediately available.	Request of detection of the current rainfall rate.
aD0!	a+r...r<CR><LF> with: r...r = rainfall rate in the unit of measurement set in the instrument (mm/h or in/h) ⇒ Example of response: 0+7.3 The instrument with address 0 measures a rate of 7.3 mm/h or in/h depending on the set unit.	Reads the current rainfall rate.
Power supply voltage and internal temperature		
aM5!	attn<CR><LF> with: ttt = number of seconds necessary for the instrument to make the measures available (3 characters) n = number of detected variables (1 character) Note: ttt = 000 means that data are immediately available.	Request of detecting the power supply voltage and the internal temperature of the rain gauge.
aD0!	a+v...v+t...t <CR><LF> with: v...v = power supply voltage in V t...t = internal temperature in the unit of measurement set in the instrument (°C or °F) ⇒ Example of response: 0+12.0+15.3 The instrument with address 0 has 12.0 power supply voltage and 15.3 °C internal temperature (if °C is the set unit).	Reads the power supply voltage and the internal temperature of the rain gauge.
Partial amount of rainfall with automatic counter reset		
aM6!	attn<CR><LF> with: ttt = number of seconds necessary for the instrument to make the measure available (3 characters) n = number of detected variables (1 character) Note: ttt = 000 means that datum is immediately available.	Request of detection of the partial amount of rainfall and subsequent reset of the corresponding counter.
aD0!	a+n+r...r<CR><LF> with: n = number of emptying of the tipping bucket r...r = partial amount of rainfall in the unit of measurement set in the instrument (mm or inches)	Reads the partial amount of rainfall and resets the corresponding counter. <i>Note:</i> as aM1! Command, but after reading, the partial rainfall counter is reset.

Type C (start concurrent measurement) commands

Command	Instrument reply	Description
Total amount of rainfall		
aC!	attn<CR><LF> with: ttt = number of seconds necessary for the instrument to make the measure available (3 characters) n = number of detected variables (1 character) Note: ttt = 000 means that datum is immediately available.	Request of detection of the total amount of rainfall.
aD0!	a+n+r...r<CR><LF> with: n = number of emptying of the tipping bucket r...r = total amount of rainfall in the unit of measurement set in the instrument (mm or inches)	Reads the total amount of rainfall.
Partial amount of rainfall		
aC1!	attn<CR><LF> with: ttt = number of seconds necessary for the instrument to make the measure available (3 characters) n = number of detected variables (1 character) Note: ttt = 000 means that datum is immediately available.	Request of detection of the partial amount of rainfall.
aD0!	a+n+r...r<CR><LF> with: n = number of emptying of the tipping bucket r...r = partial amount of rainfall in the unit of measurement set in the instrument (mm or inches)	Reads the partial amount of rainfall.
Amount of rainfall in the current day		
aC2!	attn<CR><LF> with: ttt = number of seconds necessary for the instrument to make the measure available (3 characters) n = number of detected variables (1 character) Note: ttt = 000 means that data are immediately available.	Request of detection of the amount of rainfall in the current day.
aD0!	a+n+r...r<CR><LF> with: n = number of emptying of the tipping bucket r...r = amount of rainfall in the current day in the unit of measurement set in the instrument (mm or inches)	Reads the amount of rainfall in the current day.

Command	Instrument reply	Description
Amount of rainfall in the previous day		
aC3!	atttn<CR><LF> with: ttt = number of seconds necessary for the instrument to make the measure available (3 characters) n = number of detected variables (1 character) Note: ttt = 000 means that data are immediately available.	Request of detection of the amount of rainfall in the previous day.
aD0!	a+n+r...r<CR><LF> with: n = number of emptying of the tipping bucket r...r = amount of rainfall in the previous day in the unit of measurement set in the instrument (mm or inches)	Reads the amount of rainfall in the previous day.
Rainfall rate		
aC4!	atttn<CR><LF> with: ttt = number of seconds necessary for the instrument to make the measure available (3 characters) n = number of detected variables (1 character) Note: ttt = 000 means that data are immediately available.	Request of detection of the current rainfall rate.
aD0!	a+r...r<CR><LF> with: r...r = rainfall rate in the unit of measurement set in the instrument (mm/h or in/h)	Reads the current rainfall rate.
Power supply voltage and internal temperature		
aC5!	atttn<CR><LF> with: ttt = number of seconds necessary for the instrument to make the measures available (3 characters) n = number of detected variables (1 character) Note: ttt = 000 means that data are immediately available.	Request of detecting the power supply voltage and the internal temperature of the rain gauge.
aD0!	a+v...v+t...t <CR><LF> with: v...v = power supply voltage in V t...t = internal temperature in the unit of measurement set in the instrument (°C or °F)	Reads the power supply voltage and the internal temperature of the rain gauge.

Command	Instrument reply	Description
Partial amount of rainfall with automatic counter reset		
aC6!	atttn<CR><LF> with: ttt = number of seconds necessary for the instrument to make the measure available (3 characters) n = number of detected variables (1 character) Note: ttt = 000 means that datum is immediately available.	Request of detection of the partial amount of rainfall and subsequent reset of the corresponding counter.
aD0!	a+n+r...r<CR><LF> with: n = number of emptying of the tipping bucket r...r = partial amount of rainfall in the unit of measurement set in the instrument (mm or inches)	Reads the partial amount of rainfall and resets the corresponding counter.

Type R (continuous measurements) commands

Command	Instrument reply	Description
aR0!	a+n+r...r<CR><LF> with: n = number of emptying of the tipping bucket r...r = total amount of rainfall in the unit of measurement set in the instrument (mm or inches)	Reads the total amount of rainfall.
aR1!	a+n+r...r<CR><LF> with: n = number of emptying of the tipping bucket r...r = partial amount of rainfall in the unit of measurement set in the instrument (mm or inches)	Reads the partial amount of rainfall.
aR2!	a+n+r...r<CR><LF> with: n = number of emptying of the tipping bucket r...r = amount of rainfall in the current day in the unit of measurement set in the instrument (mm or inches)	Reads the amount of rainfall in the current day.
aR3!	a+n+r...r<CR><LF> with: n = number of emptying of the tipping bucket r...r = amount of rainfall in the previous day in the unit of measurement set in the instrument (mm or inches)	Reads the amount of rainfall in the previous day.
aR4!	a+r...r<CR><LF> with: r...r = rainfall rate in the unit of measurement set in the instrument (mm/h or in/h)	Reads the current rainfall rate.
aR5!	a+v...v+t...t <CR><LF> with: v...v = power supply voltage in V t...t = internal temperature in the unit of measurement set in the instrument (°C or °F)	Reads the power supply voltage and the internal temperature of the rain gauge.

Command	Instrument reply	Description
aR6!	a+n+r...r<CR><LF> with: n = number of emptying of the tipping bucket r...r = partial amount of rainfall in the unit of measurement set in the instrument (mm or inches)	Reads the partial amount of rainfall and resets the corresponding counter.

In addition to the above-mentioned commands, the rain gauge also implements the corresponding commands with CRC, that require to add a 3-character CRC code at the end of the reply before <CR><LF>. The format of these commands is obtained from the previous by adding the letter C: aMC!, aMC1!, aMC2!, aMC3!, aMC4, aMC5!, aMC6!, aCC!, aCC1!, aCC2!, aCC3!, aCC4!, aCC5!, aCC6!, aRC0!, aRC1!, aRC2!, aRC3!, aRC4!, aRC5!, aRC6!.

6 Maintenance

Verify filters cleanliness periodically; check that there is no debris, leaves, dirt or anything else that might obstruct the flowing of water. Check that the tipping bucket contains no deposits of dirt, sand or any other obstruction. If necessary, the surfaces can be cleaned with non-aggressive detergent.

7 Safety instructions

The instrument proper operation and operating safety can be ensured only in the climatic conditions specified in this manual and if all standard safety measures as well as the specific measures described in this manual are followed.

Do not use the instrument in places where there are:

- Corrosive or flammable gases.
- Direct vibrations or shocks to the instrument.
- High-intensity electromagnetic fields, static electricity.

Do not remove the cylindrical cover of the instrument before unplugging the power cable of the heater.

Ensure that there is the system ground (Protective Earth) and the connecting cable is in good condition.

User obligations

The instrument operator shall follow the directives and regulations below that refer to the treatment of dangerous materials:

- EU directives on workplace safety.
- National law regulations on workplace safety.
- Accident prevention regulations.

8 Accessories ordering codes

The rain gauge is supplied as standard for ground installation with feet.

Bird spikes, bracket for mast installation and mast have to be ordered separately.

ACCR002 Bird spikes (8 spikes).

ACCR001 Support for installation on a mast (not included); a mast with M37 internal thread on one side is required.

POLT005 Mast Ø40 mm, internally threaded M37 on one side; length 500 mm.

POLT010 Mast Ø40 mm, internally threaded M37 on one side; length 1 m.

HD2003.75 Spike base for fixing the mast to the ground.

HD2003.78 Flat base for fixing the mast to a floor.

WARRANTY

The manufacturer is required to respond to the "factory warranty" only in those cases provided by Legislative Decree 6 September 2005 - n. 206. Each instrument is sold after rigorous inspections; if any manufacturing defect is found, it is necessary to contact the distributor where the instrument was purchased from. During the warranty period (24 months from the date of invoice) any manufacturing defects found will be repaired free of charge. Misuse, wear, neglect, lack or inefficient maintenance as well as theft and damage during transport are excluded. Warranty does not apply if changes, tampering or unauthorized repairs are made on the product. Solutions, probes, electrodes and microphones are not guaranteed as the improper use, even for a few minutes, may cause irreparable damages.


The manufacturer repairs the products that show defects of construction in accordance with the terms and conditions of warranty included in the manual of the product. For any dispute, the competent court is the Court of Padua. The Italian law and the "Convention on Contracts for the International Sales of Goods" apply.

TECHNICAL INFORMATION

The quality level of our instruments is the result of the continuous product development. This may lead to differences between the information reported in the manual and the instrument you have purchased.

We reserve the right to change technical specifications and dimensions to fit the product requirements without prior notice.

DISPOSAL INFORMATION



Electrical and electronic equipment marked with specific symbol in compliance with 2012/19/EU Directive must be disposed of separately from household waste. European users can hand them over to the dealer or to the manufacturer when purchasing a new electrical and electronic equipment, or to a WEEE collection point designated by local authorities. Illegal disposal is punished by law.

Disposing of electrical and electronic equipment separately from normal waste helps to preserve natural resources and allows materials to be recycled in an environmentally friendly way without risks to human health.



senseca.com



Senseca Italy S.r.l.
Via Marconi, 5
35050 Selvazzano Dentro (PD)
ITALY
info@senseca.com

